



NOTE: SLOPE SOFFIT PANELS 1/4" TO DRAIN AWAY FROM SIDEWALL.

SIDEWALL CONNECTION

GENERAL NOTES

1. SHEET WALL BEFORE HANGING FASCIA, DRILL HOLES IN PANELS FOR FASCIA BOLTS & SANDWICH PANEL BETWEEN THE FASCIA FRAME & THE FILLER BLOCK. THE ERECTOR IS RESPONSIBLE FOR WEATHERTIGHTNESS OF THE BUILDING AT THE FASCIA FRAME CONNECTION.
2. DEAN STD. GUTTER IS DESIGNED TO OVERFLOW DURING EXCESSIVE RAINFALL.

ENDWALL CONNECTION

DETAILS NOT NOTED SAME AS SIDEWALL CONNECTION

Sloped Fascia Cross Section